


RIPARTITORI - COLLETTORI



0514 RIPARTITORE USCITE IN LINEA						
INGRESSO	USCITE	2	3	4	5	6
1/8"	M5	0514-1/8-M5-2	0514-1/8-M5-3	0514-1/8-M5-4	0514-1/8-M5-5	0514-1/8-M5-6
1/4"	1/8"	0514-1/4"-1/8"-2	0514-1/4"-1/8"-3	0514-1/4"-1/8"-4	0514-1/4"-1/8"-5	0514-1/4"-1/8"-6
3/8"	1/8"	0514-3/8"-1/8"-2	0514-3/8"-1/8"-3	0514-3/8"-1/8"-4	0514-3/8"-1/8"-5	0514-3/8"-1/8"-6
3/8"	1/4"	0514-3/8"-1/4"-2	0514-3/8"-1/4"-3	0514-3/8"-1/4"-4	0514-3/8"-1/4"-5	0514-3/8"-1/4"-6
1/2"	3/8"	0514-1/2"-3/8"-2	0514-1/2"-3/8"-3	0514-1/2"-3/8"-4	0514-1/2"-3/8"-5	0514-1/2"-3/8"-6
1/2"	1/2"	0514-1/2"-1/2"-2	0514-1/2"-1/2"-3	0514-1/2"-1/2"-4	0514-1/2"-1/2"-5	0514-1/2"-1/2"-6



0515 RIPARTITORE USCITE CONTRAPPOSTE						
INGRESSO	USCITE	2	3	4	5	6
1/8"	M5	0515-1/8"-M5-2	0515-1/8"-M5-3	0515-1/8"-M5-4	0515-1/8"-M5-5	0515-1/8"-M5-6
1/4"	1/8"	0515-1/4"-1/8"-2	0515-1/4"-1/8"-3	0515-1/4"-1/8"-4	0515-1/4"-1/8"-5	0515-1/4"-1/8"-6
3/8"	1/8"	0515-3/8"-1/8"-2	0515-3/8"-1/8"-3	0515-3/8"-1/8"-4	0515-3/8"-1/8"-5	0515-3/8"-1/8"-6
3/8"	1/4"	0515-3/8"-1/4"-2	0515-3/8"-1/4"-3	0515-3/8"-1/4"-4	0515-3/8"-1/4"-5	0515-3/8"-1/4"-6
1/2"	3/8"	0515-1/2"-3/8"-2	0515-1/2"-3/8"-3	0515-1/2"-3/8"-4	0515-1/2"-3/8"-5	0515-1/2"-3/8"-6
1/2"	1/2"	0515-1/2"-1/2"-2	0515-1/2"-1/2"-3	0515-1/2"-1/2"-4	0515-1/2"-1/2"-5	0515-1/2"-1/2"-6



0516 RIPARTITORE 4 VIE						
INGRESSO	USCITE					
M5	M5	0516-M5				
1/8"	1/8"	0516-1/8"				
1/4"	1/4"	0516-1/4"				
3/8"	3/8"	0516-3/8"				
1/2"	1/2"	0516-1/2"				
3/4"	3/4"	0516-3/4"				



0525 RIPARTITORE 4 VIE CON FORI SPECIALI						
INGRESSO	USCITE					
M5	M5	0525-M5				
1/8"	1/8"	0525-1/8"				
1/4"	1/4"	0525-1/4"				
3/8"	3/8"	0525-3/8"				
1/2"	1/2"	0525-1/2"				
3/4"	3/4"	0525-3/4"				



0542 RIPARTITORE 4 VIE COMPATTO						
INGRESSO	USCITE					
M5	M5	0542-M5				
1/8"	1/8"	0542-1/8"				
1/4"	1/4"	0542-1/4"				
3/8"	3/8"	0542-3/8"				
1/2"	1/2"	0542-1/2"				
3/4"	3/4"	0542-3/4"				

SU RICHIESTA RIPARTITORI A DISEGNO E CON TRATTAMENTO ANODICO GRIGIO O NERO